



# Wiring guide: Promatic Radios (Built After October 2011)




Wiring side of plug

Pin L - No. 2 & Green/Yellow  
 Pin E - No. 1  
 Pin N - No. 3

Note: Pin E may be marked  $\perp$

RADIO FITTED WITH "DURAPLUG" OR "PERMAPLUG" CONNECTOR




Wiring side of plug

Pin 1 - No. 1  
 Pin 2 - No. 2 & Green/Yellow  
 Pin 3 - No. 3  
 Pin 4 - Not used

Note: Pin 4 marked  $\perp$

RADIO FITTED WITH "HIRSCHMANN" 4 PIN CONNECTOR



Assemble plug components as shown, use the rubber insert with the smaller centre hole (discard the other one)  
 After wiring fit the front section to the body and screw together firmly before tightening the rear gland nut.

**Promatic International Ltd.**  
 Hooton Road  
 Hooton  
 South Wirral  
 CH66 7PA  
[www.promatic.co.uk](http://www.promatic.co.uk)  
 Helpline: 44 (0)151 327 2220

**Promatic Inc.**  
 801, Mid America Drive,  
 Plattsburg,  
 MO 64477  
 USA  
 Website: [www.promatic.biz](http://www.promatic.biz)  
 Helpline: 1 888 767 2529 (Toll free)

