

Radio adjustment for Pigeon

A small number of traps have been built with the Black and White control wires reversed at the 3 pin plug, there is no danger from this but it may mean that the pigeon key fob radio release will not work when plugged in (Please note: footswitch operation is unaffected).

This is very easy to rectify; to do so open the control box on the side of the trap and swap over the black and white wires on the back of the switch as shown below.



Warning: Before starting work, DISARM THE TRAP and disconnect the battery

The correct method of disarming along with full operating instructions will be found in the main user manual, which should be consulted if unsure and kept for future reference.

